


Wind Meter


***ventus*** 

**V200A-UMB**



CE

UMB



[www.lufft.com](http://www.lufft.com)

**Lufft**



## Contents

<b>1 Please Read Before Use .....</b>	<b>5</b>
1.1 Symbols Used .....	5
1.2 Safety Instructions .....	5
1.3 Designated Use .....	5
1.4 Incorrect Use .....	5
1.5 Guarantee .....	5
1.6 Brand Names .....	5
<b>2 Scope of Supply .....</b>	<b>6</b>
<b>3 Order Number .....</b>	<b>6</b>
<b>4 Accessories .....</b>	<b>6</b>
<b>5 Additional Documents and Software .....</b>	<b>6</b>
<b>6 Equipment Description .....</b>	<b>7</b>
6.1 Wind .....	7
6.2 Virtual Temperature .....	7
6.3 Air Pressure .....	7
6.4 Heating .....	7
<b>7 Generation of Measurements .....</b>	<b>8</b>
7.1 Current Measurement (act) .....	8
7.2 Minimum and Maximum Values (min and max) .....	8
7.3 Average Value (avg) .....	8
7.4 Vectorial Average Value (vct) .....	8
<b>8 Measurement Output .....</b>	<b>9</b>
8.1 Virtual Air Temperature .....	9
8.2 Heating Temperature .....	9
8.3 Air Pressure .....	9
8.4 Wind Speed .....	10
8.5 Wind Direction .....	10
8.6 Wind Measurement Quality .....	11
<b>9 Installation .....</b>	<b>12</b>
9.1 Fastening .....	12
9.2 North Alignment .....	13
9.3 Selecting the Installation Location .....	14
<b>10 Connections .....</b>	<b>16</b>
10.1 Supply Voltage .....	17
10.2 RS485 Interface .....	17
10.3 Analog Interface Circuits .....	17
10.4 Control line .....	18
10.5 Connection to ISOCON-UMB (8160.USISO) .....	19
10.6 Use of surge protector (8379.USP-V) .....	19
<b>11 Commissioning .....</b>	<b>20</b>
<b>12 Configuration and Test .....</b>	<b>21</b>
12.1 Factory Settings .....	21
12.2 Configuration with the UMB-Config-Tool .....	21
12.3 Sensor Selection .....	21
12.4 Function Test with UMB-Config-Tool .....	25
12.5 Equipment Heating .....	26
<b>13 Firmware Update .....</b>	<b>27</b>
<b>14 Maintenance .....</b>	<b>27</b>
<b>15 Technical Data .....</b>	<b>28</b>
15.1 Measuring Range / Accuracy .....	29

15.2 Drawing.....	30
<b>16 EC Certificate of Conformity .....</b>	<b>31</b>
<b>17 Fault Description.....</b>	<b>32</b>
<b>18 Disposal .....</b>	<b>33</b>
18.1 Within the EC .....	33
18.2 Outside the EC .....	33
<b>19 Repair / Corrective Maintenance.....</b>	<b>33</b>
19.1 Technical Support.....	33
<b>20 Appendix .....</b>	<b>34</b>
20.1 Channel List Summary.....	34
20.2 Channel List Summary per TLS2002 FG3 .....	35
20.3 Communication in Binary Protocol.....	36
20.4 Communication in ASCII Protocol.....	39
20.5 Communication in NMEA Protocol.....	41
20.6 Communication in SDI-12 Mode .....	47
20.7 Kommunikation in Modbus Mode.....	61
<b>21 List of Figures.....</b>	<b>67</b>
<b>22 Keyword Index.....</b>	<b>68</b>

## 1 Please Read Before Use

### 1.1 Symbols Used



Important information concerning potential hazards to the user



Important information concerning the correct operation of the equipment

### 1.2 Safety Instructions



- Installation and commissioning must be carried out by suitably qualified specialist personnel only.
- Never take measurements on or touch live electrical parts.
- Pay attention to the technical data and storage and operating conditions.

### 1.3 Designated Use



- The equipment must only be operated within the range of the specified technical data.
- The equipment must only be used under the conditions and for the purposes for which it was designed.
- The safety and operation of the equipment can no longer be guaranteed if it is modified or adapted.



### 1.4 Incorrect Use

- If the equipment is installed incorrectly
- It may not function.
- It may be permanently damaged.
- Danger of injury may exist if the equipment is allowed to fall.



- If the equipment is not connected correctly
- It may not function.
- It may be permanently damaged.
- The possibility of an electrical shock may exist.

### 1.5 Guarantee

The guarantee period is 12 months from the date of delivery. The guarantee is forfeited if the designated use is violated.

### 1.6 Brand Names

All brand names referred to are subject without limitation to the valid trademark and ownership rights of the respective owner.

## 2 Scope of Supply

- Equipment
- Connection Plan

## 3 Order Number

8371.UM	<b>ventus</b> -UMB (metal)
8371.UA01	V200A-UMB (plastics)
• Wind direction	
• Wind speed	
• Virtual temperature	

## 4 Accessories

ISOCON-UMB	8160.UISO
Surge protection	8379.USP-V
Power supply unit	Recommended power supply unit: Phoenix contact 2866323 TRIO-PS/1AC/24DC/10
Connector	8371.UST1 or Amphenol C091 31D008 101 2
Connector cable	Recommended cable: 8371.UK015 15m 8371.UK050 50m

## 5 Additional Documents and Software

You can download the following documents and software via the Internet at [www.lufft.com](http://www.lufft.com).

Operating Manual	• This document
UMB-Config-Tool	• Windows® software for testing, firmware updates and configuration of UMB devices
UMB Protocol	• Communications protocol for UMB devices
Firmware	• The current device firmware

## 6 Equipment Description

**ventus** is a seawater-resistant wind meter which in addition to determining wind direction and wind speed is also capable of calculating virtual temperature.

The equipment is connected by way of an 8 pole screw connector.

The measured values can be requested over a variety of interfaces:

- RS485 interface in half or full duplex
  - o UMB binary protocol
  - o UMB ASCII protocol
  - o NMEA protocol
  - o SDI-12 protocol
  - o Modbus-RTU and Modbus-ASCII protocols
- Analog data output of 2 adjustable channels with 4-20 mA, 0 – 10V or (channel 1 only) as frequency 2 – 2000Hz

During commissioning, configuration and measurement polling takes place using the UMB-Config-Tool (Windows® PC software).

### 6.1 Wind

The wind meter uses 4 ultrasound sensors which take cyclical measurements in all directions. The resulting wind speed and direction are calculated from the measured run-time sound differential.

### 6.2 Virtual Temperature

Due to the physical relationship between the velocity of propagation of sound and the air temperature, the approximate ambient temperature can be determined with the aid of ultrasound sensors.

### 6.3 Air Pressure

The air pressure is measured by an integrated air pressure sensor

### 6.4 Heating

**ventus** is heated for winter operation.

## 7 Generation of Measurements

### 7.1 Current Measurement (act)

In accordance with the specified sampling rate, the value of the last measurement is transmitted when the current measurement value is requested. Each measurement is stored in a circular buffer for the subsequent calculation of minimum, maximum and average values.

### 7.2 Minimum and Maximum Values (min and max)

When requesting the minimum and maximum values, the corresponding value is calculated - via the circular buffer at the interval specified in the configuration (1 - 60 measurements) - and transmitted.

**Note:** In the case of wind direction, the minimum / maximum value indicates the direction at which the minimum / maximum wind speed was measured.



### 7.3 Average Value (avg)

When requesting the average value, this is calculated - via the circular buffer at the interval specified in the configuration (1 - 60 measurements) - and transmitted. In this way moving averages can also be calculated.

### 7.4 Vectorial Average Value (vct)

In the specific case of wind measurement, measurements are calculated vectorially. To this end, the average values of the vectors are generated internally. Hence the value (wind speed) and angle (wind direction) of the vector are calculated.

**Note:** On delivery, the interval for the calculation of minimum, maximum and average values is set at 60 measurements. If necessary, this can be adjusted to the particular requirements with the aid of the UMB-Config-Tool (see page 21).



## 8 Measurement Output

The factory default setting for the transmission of measurements is UMB binary protocol. You can find an example of a measurement request for the various protocols and a complete summary of the list of channels in the Appendix.

### 8.1 Virtual Air Temperature

Sampling rate 1 – 10 seconds  
 Generation of average value 1 – 60 measurements  
 Units °C; °F

Request channels:

UMB Channel				Measurement Variable	Measuring Range		
act	min	max	avg		min	max	unit
100	120	140	160	Virtual air temperature	-50.0	70.0	°C
105	125	145	165	Virtual air temperature	-58.0	158.0	°F

**Note:** In order to transmit the current measurement value the second measurement values are averaged over the sampling rate.

### 8.2 Heating Temperature

Sampling rate 1 – 10 seconds  
 Generation of average value 1 – 60 measurements  
 Units °C; °F

Request channels:

UMB Channel				Measurement Variable	Measuring Range		
act	min	max	avg		min	max	unit
112				Heating temperature top	-50.0	150.0	°C
113				Heating temperature bottom	-50.0	150.0	°C
117				Heating temperature top	-58.0	302.0	°F
118				Heating temperature bottom	-58.0	302.0	°F

### 8.3 Air Pressure

Sampling rate 10 seconds  
 Generation of average value 20 measurements  
 Units hPa

Request channels:

UMB Channel				Measurement Variable	Measuring Range		
act	min	max	avg		min	max	unit
300	320	340	360	Absolute air pressure	300.0	1200.0	hPa
305	325	345	365	Relative air pressure	300.0	1200.0	hPa

**Note:** For pressure measurement a hardware version equal or greater than 3.0 and a software version equal or greater than 1.6 is necessary!

#### 8.4 Wind Speed

Sampling rate	1 – 10 seconds
Generation of average value	1 – 60 measurements
Generation of maximum value	1 – 60 measurements based on the internal second measurement values
Units	m/s; km/h; mph; kts
Response threshold	0.1 m/s (metal) or 0.3 m/s (plastics)

Request channels:

UMB Channel					Measurement Variable	Measuring Range		
act	min	max	avg	vct		min	max	unit
400	420	440	460	480	Wind Speed	0	75.0	m/s
405	425	445	465	485	Wind Speed	0	270.0	km/h
410	430	450	470	490	Wind Speed	0	167.8	mph
415	435	455	475	495	Wind Speed	0	145.8	kts

**Note:** In order to transmit the current measurement value the second measurement values are averaged over the sampling rate.

#### 8.5 Wind Direction

Sampling rate	1 – 10 seconds
Generation of average value	1 – 60 measurements
Generation of maximum value	1 – 60 measurements based on the internal second measurement values
Response threshold	0.1 m/s (metal) or 0.3 m/s (plastics)

Request channels:

UMB Channel					Measurement Variable	Measuring Range		
act	min	max	avg	vct		min	max	unit
500	520	540		580	Wind Direction	0	359.9	°

**Note:** In order to transmit the current measurement value the second measurement values are averaged over the sampling rate.

The minimum / maximum wind direction indicates the direction at which the minimum / maximum wind speed was measured.

## 8.6 Wind Measurement Quality

Sampling rate 1 – 10 seconds

Units %

Request channels:

UMB Channel					Measurement Variable	Measuring Range		
act	min	max	avg	vct		min	max	unit
805					Wind measurement quality	0	100	%



**Note:** The value is updated every 1-10 seconds and transmits the minimum wind measurement quality for the last minute.

This value allows the user to assess how well the measurement system is functioning in the respective ambient conditions. In normal circumstances the value is 90 - 100%. Values up to 50% do not represent a general problem. If the value falls towards zero the measuring system is reaching its limits.

If during critical ambient conditions the system is no longer able to conduct reliable measurements, error value 55h (85d) is transmitted for wind speed and wind direction (device unable to execute valid measurement due to ambient conditions).

## 9 Installation

The sensor bracket is designed to be installed on the top of a mast with a diameter of 50mm or 2".

The following tools are required for the installation:

- Hexagon socket 4.0
- Compass for aligning **ventus** to the North

### 9.1 Fastening




Figure 1: Fastening to the Mast

- Loosen nuts
- Push the sensor onto the top of the mast from above
- Align the sensor to the North
- Tighten both nuts evenly and secure with locking varnish

## 9.2 North Alignment

In order for the wind direction to display correctly, the sensor must be aligned to the North. The sensor has a number of directional arrows and a North drill hole for this purpose.



Figure 2: North Markings

### Procedure:

- If the sensor is already installed, first loosen both nuts evenly until you can turn the sensor easily
- Using the compass, identify the North and fix a point of reference on the horizon
- Position the sensor in such a way that the South and North sensors are in alignment with the fixed point of reference in the North
- Tighten both nuts evenly




Figure 3: Alignment to North



**Note:** As the magnetic North Pole indicated by the compass differs from the Geographic North Pole, account must be taken of the declination (variation) at the location when aligning the sensor.

Depending on the location, the variation can be more than 15° (in North America for example). In Central Europe the variation can be largely ignored at present (< 3°). You can find further helpful information on this subject on the Internet.

### 9.3 Selecting the Installation Location

In order to guarantee long service life and correct equipment operation, please pay attention to the following points when selecting the installation location.

#### 9.3.1 General Instructions

- Stable subsurface for installing the mast
- Free access to the equipment for maintenance works
- Reliable power supply for permanent operation
- Good network coverage when transmitting over a mobile communications network

**Note:** The computed measurements specifically apply to the equipment location only. No conclusions can be drawn with regard to the wider environment or a complete road section.



#### ATTENTION:

- Only approved and tested appliances (conductors, risers etc.) should be used to install the device on the mast.
- All relevant regulations for working at this height must be observed.
- The mast must be sized and anchored appropriately.
- The mast must be **earthed** in accordance with regulations.
- The corresponding safety regulations for working at road side and in the vicinity of the road carriageway must be observed.



If the equipment is installed incorrectly

- It may not function.
- It may be permanently damaged.
- Danger of injury may exist if the equipment is allowed to fall.

#### 9.3.2 ventus


- Installation at the top of the mast
- Installation height at least 2m above the ground
- Free field around the sensor

**Note:** Buildings, bridges, embankments and trees may corrupt the wind measurement. Equally, passing traffic may cause gusts which may influence the wind measurement.



## 9.3.3 Installation Sketch


Figure 4: Installation Sketch



## 10 Connections

There is an 8 pole screw connector on the underside of the equipment. This serves to connect the supply voltage and interfaces by a connection cable.

Equipment connector:



View on cable socket solder connection

Figure 5: Connections

Pin assignment full duplex:

1	Y	Serial interface RXD-	pink
2	B	Serial interface TXD-	yellow
3		Control connection	red
4	Z	Serial interface RXD+	grey
5	A	Serial interface TXD+	green
6		Analog ground	blue
7		Supply voltage -	white
8		Supply voltage +	brown

Pin assignment half duplex/analog interface:

1		Analog interface A	pink
2	B	Serial interface RXD/TXD-	yellow
3		Control connection	red
4		Analog interface B	grey
5	A	Serial interface RXD/TXD+	green
6		Analog ground	blue
7		Supply voltage -	white
8		Supply voltage +	brown

Pin assignment SDI-12 interface:

1		-	pink
2	B	SDI-12 Data	yellow
3		SDI-12 activation	red
4		-	grey
5	A	SDI-12 GND	green
6		SDI-12 activation	blue
7		Supply voltage -	white
8		Supply voltage +	brown



**The connection cable screen must NOT be laid to ground in the control panel for Ventus!**



**The connection cable screen MUST be laid to ground in the control panel for V200A !**

If the equipment is not connected correctly

- It may not function
- It may be permanently damaged
- The possibility of an electrical shock may exist under certain circumstances

### 10.1 Supply Voltage

The supply voltage for **ventus** is 24V DC  $\pm$  10%. The power supply unit used must be approved for operation with equipment of protection class III (SELV).

### 10.2 RS485 Interface

The equipment has an electrically isolated RS485 interface for configuration, measurement polling and the firmware update.

The RS485 interface is designed as optionally half or full duplex, 2 or 4 wire connection.

The following operating restrictions exist depending on the half or full duplex operation setting:

Full duplex	Half duplex <sup>1</sup>
Autonomous telegram transmission is possible	No autonomous telegram transmission possible
Transmission of values via current output is not possible	Transmission of values via current output is possible
Heating control via control pin is possible	Heating control via control pin is possible
Triggering of NMEA telegram transmission over Control-PIN is possible	Triggering of NMEA telegram transmission over Control-PIN is not possible
SDI-12 Mode not possible	SDI-12 Mode possible
Firmware update not possible	Firmware update possible

Restrictions in full and half duplex operation

See page 28 for technical details.

### 10.3 Analog Interface Circuits

2 analog interface circuits are provided for analog data transmission.

Interface A can be configured for 0 or 4-20mA current output, 0 or 2-10V voltage output as well as for frequency output in the range from 2 – 2000Hz (with adjustable voltage level up to 10V)

Note: If the Ventus is configured for Modbus protocol it is not possible to use the frequency output!

Interface B can be configured for 0 or 4-20mA current output and 0 or 2-10V voltage output. The channels to be transmitted by way of these interfaces can be adjusted with the aid of the UMB-Config-Tool. The default values are Channels 400 (current wind speed in m/s (A)) and 500 (current wind direction (B)).

The scaling of the outputs is also adjustable.

The maximum load on the current output is 300  $\Omega$ .

<sup>1</sup> Factory setting

## 10.4 Control line

The respective function can be adjusted using the UMB-Config-Tool. The control line can be used either to control heating in half or full duplex operation or to control telegram transmission in full duplex mode. In this case control is possible by means of a volt-free switching contact.

Control line at "high" when control and analog ground are not connected.

Control line at "low" when control and analog ground are short-circuited.

For activation of the SDI-12 mode the control line is to be set to "low", i.e. control input and analog ground are to be connected.

### 10.4.1 Control line disabled

The control line level has no effect.

### 10.4.2 Heating control

- Heating is disabled when control line is at "high" level, otherwise automatic
- Heating is disabled when control line is at "low" level, otherwise automatic

### 10.4.3 Control of telegram transmission in NMEA protocol

- Telegram transmission triggered on rising edge of control voltage
- Telegram transmission triggered on falling edge of control voltage
- Telegram transmission while control voltage is "high"
- Telegram transmission while control voltage is "low"

## 10.5 Connection to ISOCON-UMB (8160.USO)




Figure 6: Connection to ISOCON-UMB



**Warning:** The power supply is **not** connected to the ISOCON-UMB but is wired direct to the power supply unit, as the ISOCON-UMB is not designed for the 240W heating duty of the **ventus** device.

Please pay attention to the ISOCON-UMB operating manual when building the equipment.

## 10.6 Use of surge protector (8379.USP-V)

Please refer to the connection example in the operating manual when using the surge protector (Order no.: 8379.USP).

## 11 Commissioning

After the equipment has been installed and connected correctly, the sensor begins autonomously to take measurements. A Windows® PC with serial interface, UMB-Config-Tool software and interface cable (SUB-D 9 pole; jack - socket; 1:1) are required for configuration and test purposes.

Attention must be paid to the following points:

- Check for correct equipment operation on site by carrying out a measurement with the aid of the UMB-Config-Tool (see page 25).
- The device must be aligned to the North in order to ensure correct wind measurement (see page 13).
- If several **ventus** devices are operated on a UMB network, a unique device ID must be assigned to each device (see page 22).

There is no protective cover to remove on the sensor itself.

## 12 Configuration and Test

Lufft provides Windows® PC software (UMB-Config-Tool) for configuration purposes. The sensor can also be tested and the firmware updated with the aid of this software.

### 12.1 Factory Settings

The **ventus** device is delivered with the following settings:

Class ID:	8 (cannot be modified)
Device ID:	1 (gives address 8001h = 28673d)
Baud rate:	19200
RS485 protocol:	Binary / half duplex
Measurement interval:	10 seconds
Average value generation:	60 measurements
Analog interface:	Channels 400 (current wind speed in m/s (A)) and 500 (current wind direction (B))
Analog mode:	4 – 20 mA
Scaling digital:	0 - 75 m/s bzw. 0° - 3593,9°
Scaling analog:	4 – 20 mA
Error current:	2 mA
Control line:	Disabled
Heating:	Automatic



**Note:** The device ID must be changed if several **ventus** devices are operated on a UMB network, as each device requires a unique ID. It makes sense to start from ID 1 and continue in ascending order.

### 12.2 Configuration with the UMB-Config-Tool

The operation of the UMB-Config-Tool is described in detail in the operating instructions for the Windows® PC software. For this reason only the menus and functions specific to the **ventus** devices are described here.

### 12.3 Sensor Selection

The **ventus** is shown here with sensor selection **ventus** (Class ID 8).




Figure 7: Sensor Selection



**Note:** If the UMB-Config-Tool does not recognize the **ventus** sensor type, select the number '8' under 'Sensor Type'. With **ventus** connected, click on 'Update Channel List'. You can then request measurements in order to test the sensor.

However, you do require the current version of the UMB-Config-Tool to configure **ventus**.



**Note:** All other devices which are used in the polling process, e.g. modems, LCOM etc., must be disconnected from the UMB network during configuration.

### 12.3.1 Configuration

After a configuration has been loaded, all relevant settings and values can be adjusted. Depending on the device type, only the settings pertinent to the respective available sensors are relevant.

### 12.3.2 General Settings




Figure 8:General Settings

ID: Device ID (factory setting 1; assign device IDs to additional devices in ascending order).

Description: In order to differentiate the devices you can enter a description here, e.g. the location.

Baud rate: Transmission speed of the RS485 interface (factory setting 19200 (DO NOT CHANGE for operation with ISOCON-UMB)).

Protocol: Communications protocol of the sensor (binary, ASCII, NMEA, SDI-12, terminal, Modbus-RTU, Modbus-ASCII)

Timeout: In the event of a temporary changeover of the communications protocol, the system switches back to the configured protocol after this time (in minutes) (no function at present).

### 12.3.3 Wind Settings




Figure 9:Wind Settings

Interval/average: Adjustment how often a new value is measured and how many values are part of average calculation.

Windspeed min: Approach velocity onto the wind meter with effect from which a measurement is transmitted, in the unit of the accompanying channel.

Heater mode: The device can be configured for heating in different operating modes. You can find a precise description of the operating modes on page 26.

### 12.3.4 NMEA Settings




Figure 10:NMEA Settings

Here it is possible to adjust the NMEA-specific values for TT (Independent telegram transmission), OS (Scaling of wind speed), TG (Control line trigger property) and OR (Output interval). You can find a precise description of the operating modes on page 41.

### 12.3.5 Analog output Settings




Figure 11:Analog output Settings: Current Mode

First the operating mode of the analog output has to be selected. For analog output 1 Off (deactivated), current (0/4..20mA), voltage (0/2..10V) and frequency (2..2000Hz) are available. Analog output 2 can be operated in Off, current and voltage mode.

Then select the channels for the analog output and adjust the scaling. For the analog limits (default 4-20 mA) you have to set the digital limits (for example 0 – 75 m/s).

Example:

With the above limits the analog value for a wind speed of 10 m/s will be  $(20\text{mA}-4\text{mA}) / (75\text{m/s}-0\text{m/s}) * 10\text{m/s} + 4\text{mA} = 6.13\text{mA}$ .

The settings in case of voltage mode operation are similar, except of the different limits for the output values.




Figure 12:Analog output Settings: Voltage Mode

When operating the analog output in frequency mode, additionally the voltage level for the frequency output, i.e. the voltage in case of "high" level, has to be adjusted (5.0V (default) in this example)




Figure 13: Analog output Settings: Frequency Mode

## 12.4 Function Test with UMB-Config-Tool

The functions of the **ventus** can be tested with the UMB-Config-Tool by polling various channels.



**Note:** All other devices which are used in the polling process, e.g. modems, LCOM etc., must be disconnected from the UMB network during the function test.

### 12.4.1 Channels for Measurement Polling

You can select the channel for measurement polling by the UMB-Config-Tool by clicking on the respective channel.

ChNr.	Measurement	Unit	Range	active
100	Act. virtual temperature	°C	-50.00 .. 70.00	active
120	Min. virtual temperature	°C	-50.00 .. 70.00	inactive
140	Max. virtual temperature	°C	-50.00 .. 70.00	inactive
160	Avg. virtual temperature	°C	-50.00 .. 70.00	inactive
105	Act. virtual temperature	°F	-58.00 .. 158.00	inactive
125	Min. virtual temperature	°F	-58.00 .. 158.00	inactive
145	Max. virtual temperature	°F	-58.00 .. 158.00	inactive
165	Avg. virtual temperature	°F	-58.00 .. 158.00	inactive
400	Act. wind speed	m/s	0.00 .. 75.00	active
420	Min. wind speed	m/s	0.00 .. 75.00	inactive
440	Max. wind speed	m/s	0.00 .. 75.00	inactive
460	Avg. wind speed	m/s	0.00 .. 75.00	inactive

Figure 14: Measurement Polling Channels

### 12.4.2 Example of Measurement Polling

VENTUS-UMB ID1 virtual temperature [°C] Act	VENTUS-UMB ID1 wind speed [m/s] Act	VENTUS-UMB ID1 wind direction [°] Act
24.99	0.74	355.71
24.13	0.95	356.88
24.13	0.95	356.88
24.11	0.97	357.48
24.11	0.97	357.48
23.87	0.97	357.48
23.87	0.85	354.00
23.87	0.85	354.00
23.87	0.85	354.00
23.87	0.85	354.00
23.87	0.85	354.00
23.87	0.85	354.00
23.87	0.85	354.00

Figure 15: Example of Measurement Polling



**Note:** The UMB-Config-Tool is provided for test and configuration purposes only. It is not suitable for the permanent acquisition of measurement data. We recommend the use of professional software solutions for this purpose, e.g. SmartView3.

## 12.5 Equipment Heating

**ventus** has 2 heating elements (one element only on plastic version) to keep the sensor free of snow and ice. One element is in the cover (metal version only) and the other is built into the ultrasonic sensors.

### 12.5.1 Heating mode

The heating of the device can be operated in 4 different modes:

0x00: Heating always off

0x01: Automatic heating control<sup>1</sup>

The heating switches on when the housing temperature falls below +15°C (adjustable between 2°C and 70°C) and switches off at a housing temperature of >+20°C (set temperature +5°C) (**metal**)

The heating switches on when the housing temperature falls below +50°C (adjustable between 2°C and 70°C) and switches off at a housing temperature of >+55°C (set temperature +5°C) (**plastics**)

0x02: The switch-on temperature is adjusted to +40°C; in this condition the heating switches on at room temperature (for test purposes only)

0x03: Heating control is disabled when the control line is at the “high” level, else automatic

0x04: Heating control is disabled when the control line is at the “low” level, else automatic

### 12.5.2 Heating capacity

The heating capacity can be set in accordance with the following modes:

0x00: Full heating capacity (ca. 240W)<sup>1</sup>

0x01: Alternating heating:

Cover plate alternating to base plate (ca. 100W or 150W alternating)

The next level of heating switches in if the pre-set temperature for the respective level is not reached within 4 minutes.

---

<sup>1</sup> Factory setting

## 13 Firmware Update

To keep the sensor in accordance with the latest state-of-the-art, it is possible to carry out a firmware update on site with no need to remove the sensor and return it to the manufacturer.

The firmware update is carried out with the aid of the UMB-Config-Tool.

The firmware update is only possible in half-duplex mode.

The description of the firmware update can be found in the instructions for the UMB-Config-Tool. Please download the latest firmware and UMB-Config-Tool from our website [www.lufft.de](http://www.lufft.de) and install it on a Windows® PC. You can find the instructions here:



## 14 Maintenance

In principle the equipment is maintenance-free.

However, it is recommended to carry out a functional test on an annual basis. When doing so, pay attention to the following points:

- Visual inspection of the equipment for soiling
- Check the sensors by carrying out a measurement request

## 15 Technical Data

Power supply: 24VDC  $\pm$  10%  
12VDC if **no** heating is used

Current consumption and power input - sensor:  
ca. 50mA / 1.2VA at 24VDC

Current consumption and power input with heating (metal):  
ca. 10A / 240VA at 24VDC

Current consumption and power input with heating (plastics):  
ca. 900mA / 21.6VA at 24VDC

Dimensions including mounting bracket:  
 $\varnothing$  150mm, height 145mm

Weight including mounting bracket, excluding connection cable:  
ca. 1.63 kg (metal)  
ca. 0,80 kg (plastics)

Fastening: Mast with  $\varnothing$  50mm

Protection class: III (SELV)  
Protection type: IP65

### Storage conditions

Permissible storage temperature: -55°C ... +80°C  
Permissible relative humidity: 0 ... 95% RH  
Non-condensing

### Operating conditions

Permissible operating temperature: -40°C ... +60°C (with heating)  
Permissible operating temperature: -20°C ... +60°C (without heating)  
Permissible relative humidity: 0 ... 100% RH  
Permissible altitude above sea level: N/A

### RS485 interface, 2<sup>1</sup> or 4 wire, half<sup>1</sup> or full duplex

Data bits: 8 (SDI-12 mode: 7)  
Stop bit: 1  
Parity: No (SDI-12 mode: even)  
Tri-state: 2 bits after stop bit edge  
Adjustable baud rates: 1200, 2400, 4800, 9600, 14400, 19200<sup>1</sup>, 28800, 57600  
(when entering SDI-12 mode the circuit is switched to conform to the standard's requirements)

Analog interface circuits: A: 0 or 4 - 20mA / 0 or 2 – 10V / 2 – 2000Hz  
B: 0 or 4 - 20mA / 0 or 2 – 10V

Maximum load: 300  $\Omega$  (in current mode)  
Resolution: 16 bits  
Channels: Adjustable  
Update rate: 1-10 seconds

Housing: Seawater-resistant aluminum AlMg3Si

<sup>1</sup> Factory setting and baud rate for firmware update

AlMg3Si

## 15.1 Measuring Range / Accuracy

### 15.1.1 Wind Speed

Measurement process:	Ultrasound
Measuring range:	0 – 75m/s
Resolution:	0.1m/s
Accuracy:	$\pm 0.2$ m/s or $\pm 2\%$ RMS (metal) (the higher value) $\pm 0.3$ m/s oder $\pm 3\%$ (0 ... 35m/s) RMS (plastics) (the higher value) $\pm 5\%$ (> 35m/s) RMS (Kunststoff)
Response threshold (adjustable):	0.1 m/s (metal) 0.3 m/s (plastics)
Sampling rate:	1-10 seconds
Units:	m/s; km/h; mph; kts

### 15.1.2 Wind Direction


Measurement process:	Ultrasound
Measuring range:	0 – 359.9°
Resolution:	0.1°
Accuracy:	< 2° (> 1m/s) RMSE (metal) < 3° (> 1m/s) RMSE (plastics)
Response threshold (adjustable):	0.1 m/s (metal) 0.3 m/s (plastics)
Sampling rate:	1-10 seconds

### 15.1.3 Virtual Temperature

Measurement process:	Ultrasound
Measuring range:	-50°C ... +70°C
Resolution:	0.1°C
Sensor accuracy:	+/- 2.0 K (unheated and without solar irradiation)
Sampling rate:	1-10 seconds
Units:	°C; °F

### 15.1.4 Air Pressure

Measurement process:	MEMS sensor - capacitive
Measuring range:	300 ... 1200hPa
Resolution:	0.1hPa
Accuracy:	+/- 1.5hPa
Sampling rate:	10sec
Unit:	hPa

**15.2 Drawing**Figure 16: **ventus**

## 16 EC Certificate of Conformity

**Product: Wind Meter**

Type: ***ventus*** (Order No.: 8371.UM)

We herewith certify that the above mentioned equipment complies in design and construction with the Directives of the European Union and specifically the EMC Directive in accordance with 89/336/EC and the Low Voltage Directive in accordance with 73/23/EC.

The above mentioned equipment conforms to the following specific EMC Standards:

EN 61000-6-2:2005 Part 6-2: Generic Standards - Immunity for Industrial Environments

EN 61000-4-2	ESD
EN 61000-4-3	Radiated electromagnetic field
EN 61000-4-4	Burst
EN 61000-4-5	Surge
EN 61000-4-6	Conducted disturbances
EN 61000-4-8	Magnetic field 50Hz

## EN 61000-6-3:2001 Part 6-3: Generic Standards - Emission Standard for Residential, Commercial and Light Industrial Environments

EN 55022:1998 +A1:2000 +A2:2003 Line-conducted disturbances  
prEN 50147-3:2000 Radiated emission  
IEC / CISPR 22 Class B

IEC 60945 vibration check

MIL-Std 810 Verfahren 509.3 Saline mist check  
MIL-Std 810F Method 521.2 Icetest

Fellbach, 01.10.2009

## 17 Fault Description

Fault Description	Cause - Remedy
The device does not allow polling or does not respond	<ul style="list-style-type: none"> <li>- Check supply voltage</li> <li>- Check interface connection</li> <li>- False device ID → check ID; devices are delivered with ID 1.</li> </ul>
Wind direction transmits incorrect values	Device not correctly aligned → check alignment of device to North.
Device transmits error value 28h (40d)	Device is in initialization phase after start-up → device delivers measurement values after ca. 10 seconds
Device transmits error value 50h (80d)	Device is being operated above the specified measuring range
Device transmits error value 51h (81d)	Device is being operated below the specified measuring range
Device transmits error value 55h (85d) for wind measurement	<p>Device unable to carry out valid measurement due to ambient conditions.</p> <p>There may be several causes for this:</p> <ul style="list-style-type: none"> <li>- Device is being operated above the specified measuring range</li> <li>- Very strong horizontal rain or snowfall</li> <li>- <b>ventus</b> sensors are heavily soiled → clean sensor</li> <li>- <b>ventus</b> sensors are iced up → check heating mode in configuration and verify function / connection of heating</li> <li>- There are foreign bodies in the <b>ventus</b> measuring section</li> <li>- One of the <b>ventus</b> sensors is faulty → return device to manufacturer for repair</li> </ul>
The quality of the wind measurement is not always 100%	<p>The device should always transmit 90 – 100% in normal operation. Values of up to 50% do not represent a general problem.</p> <p>When error value 55h (85d) is transmitted, this value is 0%.</p> <p>The device may be faulty if it permanently transmits values below 50%.</p>
Device transmits an error value not listed here	There may be several reasons for this behavior → contact the manufacturer's technical support service.
Minimum value of wind direction is greater than maximum value	In the case of wind direction, the minimum / maximum value indicates the direction at which the minimum / maximum wind speed was measured.

## 18 Disposal

### 18.1 Within the EC



The device must be disposed of in accordance with European Directives 2002/96/EC and 2003/108/EC (waste electrical and electronic equipment). Waste equipment must not be disposed of as household waste! For environmentally sound recycling and the disposal of your waste equipment please contact a certified electronic waste disposal company.

### 18.2 Outside the EC

Please comply with the applicable regulations for the proper disposal of waste electrical and electronic equipment in your respective country.

## 19 Repair / Corrective Maintenance

Please arrange for any faulty equipment to be checked and, if necessary, repaired by the manufacturer exclusively. Do not open the equipment and do not under any circumstances attempt to carry out your own repairs.

In matters of guarantee or repair please contact:

### G. Lufft Mess- und Regeltechnik GmbH

Gutenbergstraße 20  
70736 Fellbach  
Postfach 4252  
70719 Fellbach  
Germany  
Tel: +49 711 51822-0  
Hotline: +49 711 51822-52  
Fax: +49 711 51822-41  
E-Mail: [info@lufft.com](mailto:info@lufft.com)

or your local distributor.

### 19.1 Technical Support

Our Hotline is available for technical questions via the following e-mail address:

[hotline@lufft.de](mailto:hotline@lufft.de)

You can also consult frequently asked questions at <http://www.lufft.com/> (menu header: FAQs).

## 20 Appendix

### 20.1 Channel List Summary

The channel assignment described here applies to online data requests in binary and ASCII protocol.

UMB Channel				special	Measurement Variable (float)	Measuring Range		
act	min	max	avg			min	max	unit
<b>Temperature</b>								
100	120	140	160		virtual temperature	-50.0	70.0	°C
105	125	145	165		virtual temperature	-58.0	158.0	°F
112					Heating temperature top	-50.0	150.0	°C
113					Heating temperature bottom	-50.0	150.0	°C
117					Heating temperature top	-58.0	302.0	°F
118					Heating temperature bottom	-58.0	302.0	°F
<b>Air Pressure</b>								
300	320	340	360		Absolute air pressure	300.0	1200.0	hPa
305	325	345	365		Relative air pressure	300.0	1200.0	hPa
<b>Wind</b>								
				vect. avg				
400	420	440	460	480	wind speed	0	75.0	m/s
405	425	445	465	485	wind speed	0	270.0	km/h
410	430	450	470	490	wind speed	0	167.8	mph
415	435	455	475	495	wind speed	0	145.8	kts
500	520	540		580	wind direction	0	359.9	°
805					wind value quality	0	100,0	%

## 20.2 Channel List Summary per TLS2002 FG3

The following channels are available specifically for data requests for further processing in TLS format. These channels are available in binary protocol only.

DE Type	UMB Channel	Meaning	Format	Range	Resolution	Coding
48	1048	Result message Air Temperature AT	16 bit	-30 ... +60°C	0.1°C	60.0 = 600d = 0258h 0.0 = 0d = 0000h -0.1 = -1d = FFFFh -30.0 = -300d = FED4h
54	1054	Result Message Air Pressure LD	16 bit	800 ... 1200 hPa	1 hPa	800 = 800d = 0320h 1200 = 1200d = 04B0h
56	1056	Result message Wind Direction WD	16 bit	0 ... 359°	1°	0° (N) = 0d = 0000h 90° (O) = 90d = 005Ah 180° (S) = 180d = 00B4h 270° (W) = 270d = 010Eh FFFFh = not definable
57	1057	Result message Wind Speed. (average) WSA	16 bit	0.0 ... 75.0 m/s	0.1 m/s	0.0 = 0d = 0000h 75.0 = 750d = 02EEh
64	1064	Result message Wind Speed (peak) WSP	16 bit	0.0 ... 75.0 m/s	0.1 m/s	0.0 = 0d = 0000h 75.0 = 750d = 02EEh

## 20.3 Communication in Binary Protocol

Only one example of an online data request is described in this operating manual. Please refer to the current version of the UMB Protocol for all commands and the exact mode of operation of the protocol (available for download at [www.lufft.com](http://www.lufft.com)).

**Note:** Communication with the sensor takes place in accordance with the master-slave principle, i.e. there may only be ONE requesting unit on a network.



### 20.3.1 Framing

The data frame is constructed as follows:

1	2	3 - 4	5 - 6	7	8	9	10	11 ... (8 + len) optional	9 + len	10 + len 11 + len	12 + len
SOH	<ver>	<to>	<from>	<len>	STX	<cmd>	<verc>	<payload>	ETX	<cs>	EOT

SOH	Control character for the start of a frame (01h); 1 byte
<ver>	Header version number, e.g.: V 1.0 → <ver> = 10h = 16d; 1 byte
<to>	Receiver address; 2 bytes
<from>	Sender address; 2 bytes
<len>	Number of data bytes between STX and ETX; 1 byte
STX	Control character for the start of payload transmission (02h); 1 byte
<cmd>	Command; 1 byte
<verc>	Version number of the command; 1 byte
<payload>	Data bytes; 0 – 210 bytes
ETX	Control character for the end of payload transmission (03h); 1 byte
<cs>	Check sum, 16 bit CRC; 2 bytes
EOT	Control character for the end of the frame (04h); 1 byte

Control characters: SOH (01h), STX (02h), ETX (03h), EOT (04h).

### 20.3.2 Addressing with Class and Device ID

Addressing takes place by way of a 16 bit address. This breaks down into a Class ID and a Device ID.

Address (2 bytes = 16 bit)			
Bits 15 – 12 (upper 4 bits)		Bits 11 – 8 (middle 4 bits)	Bits 7 – 0 (lower 8 bits)
Class ID (0 to 15)		Reserve	Device ID (0 – 255)
0	Broadcast		0 Broadcast
8	ventus		1 - 255 Available
15	Master or control devices		

ID = 0 is provided as broadcast for classes and devices. Thus it is possible to transmit a broadcast on a specific class. However this only makes sense if there is only one device of this class on the bus; or in the case of a command, e.g. reset.

### 20.3.3 Examples for Creating Addresses

If, for example, you want to address **ventus** with the device ID 001, this takes place as follows:

The class ID for the **ventus** is 8d = 8h;

the device ID is e.g. 001d = 01h

Putting the class and device IDs together gives the address 8001h (32769d).

### 20.3.4 Example of a Binary Protocol Request

If, for example, a **ventus** with the device ID 001 is to be polled from a PC for the current temperature, this takes place as follows:

#### Sensor:

The class ID for the **ventus** is 8 = 8h;

the device ID is 001 = 01h

Putting the class and device IDs together gives a target address of 8001h.

#### PC:

The class ID for the PC (master unit) is 15 = Fh;

the PC ID is e.g. 001d = 01h

Putting the class and device IDs together gives a sender address of F001h.

The length **<len>** for the online data request command is 4d = 04h;

the command for the online data request is 23h;

the version number of the command is 1.0 = 10h.

The channel number is in **<payload>**; as can be seen from the channel list (page **Fehler! Textmarke nicht definiert.**), the current temperature in °C in the channel is 100d = 0064h.

The calculated CRC is 540Bh.

#### The request to the device:

SOH	<ver>	<to>		<from>		<len>	STX	<cmd>	<verc>	<channel>		ETX	<cs>		EOT
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
01h	10h	01h	80h	01h	F0h	04h	02h	23h	10h	64h	00h	03h	0Bh	54h	04h

#### The response from the device:

SOH	<ver>	<to>		<from>		<len>	STX	<cmd>	<verc>	<status>	<channel>	<typ>	
1	2	3	4	5	6	7	8	9	10	11	12	13	14
01h	10h	01h	F0h	01h	80h	0Ah	02h	23h	10h	00h	64h	00h	16h

<value>				ETX	<cs>		EOT
15	16	17	18	19	20	21	22
00h	00h	B4h	41h	03h	1Fh	94h	04h

#### Interpretation of the response:

<status> = 00h device o.k. (≠ 00h signifies error code; see page 38)

<typ> = Data type of the following value; 16h = float (4 bytes, IEEE format)

<value> = 41B40000h corresponds to a float value of 22.5

The temperature is therefore 22.5°C.

The correct data transmission can be checked with the aid of the check sum (941Fh).

**Note:** Little Endian (Intel, low byte first) applies when transmitting word and float variables of addresses or the CRC, for example. This means first the low byte and then the high byte.



### 20.3.5 Status and Error Codes in Binary Protocol

If a measurement request delivers the <status> 00h, the sensor is working correctly. You can find a complete list of additional codes in the description of the UMB protocol.

Extract from list:

<status>	Description
00h (0d)	Command successful; no error; all o.k.
10h (16d)	Unknown command; not supported by this device
11h (17d)	Invalid parameter
24h (36d)	Invalid channel
28h (40d)	Device not ready; e.g. initialization / calibration running
50h (80d)	Measurement variable (+offset) is outside the set display range
51h (81d)	
52h (82d)	Measurement value (physical) is outside the measuring range (e.g. ADC over range)
53h (83d)	
54h (84d)	Error in measurement data or no valid data available
55h (85d)	Device /sensor unable to carry out valid measurements due to ambient conditions

### 20.3.6 CRC Calculation

CRC is calculated according to the following rules:

Norm: CRC-CCITT

Polynomial:  $1021h = x^{16} + x^{12} + x^5 + 1$  (LSB first mode)

Start value: FFFFh

You can find further information in the description of a CRC calculation in UMB Protocol.

## 20.4 Communication in ASCII Protocol

Text-based communication with devices is possible using ASCII protocol.

To do this, in the device configuration, interface settings, the protocol mode must be set to ASCII (see page 22).

ASCII protocol is network-compatible and serves exclusively for online data requests. The device will not respond to incomprehensible ASCII commands.



**Note:** The use of binary protocol is recommended for lengthy transmission routes (e.g. network, GPRS/UMTS), as ASCII protocol is unable to detect transmission errors (not CRC-secured).



**Note:** TLS channels are not available in ASCII protocol.

### 20.4.1 Structure

An ASCII command is introduced by the ‘&’ character and completed by the CR (0Dh) sign. There is a space character (20h) between the individual blocks in each case; this is represented by an underscore character ‘\_’. Characters that represent an ASCII value are in ordinary inverted commas.

### 20.4.2 Summary of ASCII Commands

Command	Function	BC	AZ
M	Online data request		I
X	Switches to binary protocol		k
R	Triggers software reset	●	k
D	Software reset with delay	●	k
I	Device information		k

These operating instructions describe the online data request only. You can find the description of the other commands in the UMB protocol.

### 20.4.3 Online Data Request (M)

**Description:** By way of this command, a measurement value is requested from a specific channel.

**Request:** ‘&’\_<ID><sup>5</sup> ‘M’\_<channel><sup>5</sup> CR

**Response:** ‘\$’\_<ID><sup>5</sup> ‘M’\_<channel><sup>5</sup>\_<value><sup>5</sup> CR

<ID><sup>5</sup> Device address (5 decimal places with leading zeros)

<channel><sup>5</sup> Indicates the channel number (5 decimal places with leading zeros)

<value><sup>5</sup> Measurement value (5 decimal places with leading zeros); a measurement value standardized to 0 – 65520d. Various error codes are defined from 65521d – 65535d.

**Example:**

Request: &\_32769\_M\_00100

By way of this request, channel 100 of the device with address 32769 (ventus with device ID 001).

Response: \$\_32769\_M\_00100\_34785

This channel outputs a temperature from –40 to +60°C; this results in the following calculation:

0d corresponds to -50°C

65520d corresponds to +70°C

36789d corresponds to  $[+70^\circ\text{C} - (-50^\circ\text{C})] / 65520 * 34785 + (-50^\circ\text{C}) = 13,7^\circ\text{C}$

**Note:** TLS channels are not available in ASCII protocol.



#### 20.4.4 Standardization of Measurement Values in ASCII Protocol

The standardization of measurement values from 0d – 65520d corresponds to the measuring range of the respective measurement variable.

Measurement Variable	Measuring Range		
	min	max	unit
<b>Temperature</b>			
Temperature	-50.0	70.0	°C
	-58.0	158.0	°F
<b>Air Pressure</b>			
Relative air pressure	300,0	1200,0	hPa
Absolute air pressure			
<b>Wind</b>			
Wind speed	0.0	75.0	m/s
	0.0	270.0	km/h
	0.0	167.8	mph
	0.0	145.8	kts
Wind direction	0.0	359.9	°
Quality of wind measurement	0.0	100.0	%

#### 20.4.5 Status and Error Codes in ASCII Protocol

Various error codes are defined from 65521d – 65535d in addition to the standardization of measurement values.

##### Codes:

<code>	Description
65521d	Invalid channel
65523d	Measurement value outside measuring range (too high)
65524d	Measurement value outside measuring range (too low)
65525d	Measurement data error or no valid data available
65526d	Device / sensor unable to execute valid measurement due to ambient conditions
65534d	Invalid calibration
65535d	Unknown error

## 20.5 Communication in NMEA Protocol

Wind direction and wind speed in accordance with NMEA protocol can be requested via the NMEA protocol.

To do this, in the device configuration, interface settings, the protocol mode must be set to NMEA (see page **Fehler! Textmarke nicht definiert.**).

NMEA protocol is network-compatible and serves exclusively for online data requests. The device will not respond to incomprehensible NMEA commands.

**Note:** The use of binary protocol is recommended for lengthy transmission routes (e.g. network, GPRS/UMTS), as NMEA protocol is unable to detect transmission errors (not CRC-secured).



**Note:** In the NMEA protocol, data output is available by means of NMEA telegram only.



In the NMEA protocol, it is possible to control the telegram output by means of the control line when using full duplex operation (see page 18).

### 20.5.1 Structure

An NMEA command is initiated by the ID and concluded with the CR sign (0Dh). Characters that represent an ASCII value are in ordinary inverted commas.

### 20.5.2 ID

The NMEA-ID is derived from the UMB-ID, by deducting 1.

Example:      UMB-ID:      1  
                   NMEA-ID:      0

### 20.5.3 Summary of NMEA commands

Command	Function
TR	Telegram request
TT	Independent telegram transmission
KY	Access mode (read only/admin)
DM	Duplex mode
HP	Heating duty
HT	Heating mode
ID	Device ID
MD	Measurement interval
OR	Output interval
OS	Scaling of wind speed
RS	Triggers software reset
TG	Control line trigger property
XX	Switches to binary protocol

Differentiation is made between 2 authorization levels when sampling:

- Read only and
- Admin

The settings for all parameters can be requested in both modes but can only be changed in "Admin" mode. In "Read only" mode it is only possible to enable automatic telegram transmission and to trigger a software reset.

#### 20.5.4 Telegram request (NMEA)

**Description:** This command requests the NMEA telegram.

**Request:** <ID>'TR4'(CR)

<ID> Device address (2 decimal places with leading zeros)

**Response:** \$WIMWV,xxx.x,R,xxx.x,M,A\*xx(CR)(LF)

\$WIMWV, fix

xxx.x Wind direction

,R, fix

xxx.x Wind speed

, fix

M Possible values K,N,M,S for km/h, Knots, m/s, mph

, fix

A A=valid value, V= invalid value

\* Check sum identifier

xx Check sum (high byte first)

CR Carriage Return

LF Line Feed

#### Response in case of error

**Request:** <ID>'TR4'(CR)

<ID> Device address (2 decimal places with leading zeros)

**Response:** \$WIMWV,,R,,M,V\*(CR)(LF)

\$WIMWV, fix

,R, fix

, fix

M Possible values K,N,M,S for km/h, Knots, m/s, mph

, fix

V V= invalid value

\* Check sum identifier

xx Check sum (high byte first)

CR Carriage Return

LF Line Feed

#### Example:

Request: 01TR4

Response: \$WIMWV,230.6,R,003.4,N,A\*23

This means that the wind is coming at a speed of 3.4 knots from 230.6°

### 20.5.5 Independent telegram transmission (NMEA)

**Description:** This command is used to disable/enable independent transmission of the NMEA telegram. Independent transmission can be enabled in full duplex mode only.

**Response:** <ID>'TT'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0...disabled

4...enabled

The current setting is delivered as the response if no entry is made for <value>.

**Response:** \$WIMWV,xxx.x,R,xxx.x,M,A\*xx(CR)(LF) every 1-10 seconds (depending on MD)

\$WIMWV, fix

xxx.x Wind direction

,R, fix

xxx.x Wind speed

, fix

M Possible values K,N,M,S for km/h, Knots, m/s, mph

, fix

A A=valid value, V= invalid value

\* Check sum identifier

xx Check sum (high byte first)

CR Carriage Return

LF Line Feed

#### Response in case of error

**Request:** <ID>'TT'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0...disabled

4...enabled

**Response:** \$WIMWV,,R,,M,V\*(CR)(LF)

\$WIMWV, fix

,R, fix

, fix

M Possible values K,N,M,S for km/h, Knots, m/s, mph

, fix

V V= invalid value

\* Check sum identifier

xx Check sum (high byte first)

CR Carriage Return

LF Line Feed

### 20.5.6 Access mode

**Description:** This command is used to switch between Read only and Admin modes.

**Request:** <ID>'KY<key>(CR)

<ID> Device address (2 decimal places with leading zeros)

<key> 0 Read only

4711 Admin

It is possible to set all parameters in Admin mode only. The parameters are effective immediately after setting; however they are only stored permanently in the sensor in Read only mode **after** quitting Admin mode. Parameters that were changed in error but not yet saved can be reset by briefly disconnecting the sensor from the power supply.

**Response on change from Read only mode to Admin mode:**

!00KY04711

Setting rights -> ADMIN

Save new configuration with 'idKY00'

**Response on change from Admin mode to Read only mode:**

!00KY00000

Setting rights -> READ ONLY

Configuration saved.

### 20.5.7 Duplex mode

**Description:** This command is used to switch between half and full duplex.

**Note:** Switchover takes place immediately, i.e. a suitable communication module must then be connected to the sensor. If the switchover is made in error, the previous setting can be restored by briefly disconnecting the sensor from the power supply.

**Request:** <ID>'DM<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0 ...half duplex

1...full duplex

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.8 Heating duty

**Description:** This command is used to switch between full and half heating duty.

**Request:** <ID>'HP<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0 ...full heating duty

1... alternating heating

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.9 Heating mode

**Description:** This command is used to switch between 4 heating modes. The trigger property TG is automatically set to 0 (disabled) when the setting values are 3 or 4.

**Request:** <ID>'HT'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0: Heating is always off

1: Heating is automatically controlled<sup>1</sup>

Heating switches on when the housing temperature falls below +2°C (adjustable between 2°C and 10°C) and switches off at a housing temperature of >+7°C (set temperature +5°C)

2: The switch-on temperature is shifted to +40°C; thus the heating switches on at room temperature (for test purposes only)

3: Heating is disabled when the control line is at "high" level, otherwise automatic

4: Heating is disabled when the control line is at "low" level, otherwise automatic

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.10 Device ID

**Description:** This command is used to set the sensor ID.

**Request:** <ID>'ID'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> New ID

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.11 Measurement interval

**Description:** This command is used to set the measurement interval.

**Request:** <ID>'MD'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0..10 seconds

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.12 Output interval

**Description:** This command is used to set the time interval for telegram transmission when independent telegram transmission (TT) is enabled.

**Request:** <ID>'OR'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0..10 seconds

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

<sup>1</sup> Factory setting

### 20.5.13 Scaling the wind speed

**Description:** This command is used to set the unit for wind speed.

**Request:** <ID>'OS'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0 ... m/s

1...km/h

2...miles/h

3...knots

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.14 Control line trigger property

**Description:** This command is used to set the trigger property when independent telegram transmission (TT) is enabled. If when enabling the function the heating control setting is 3 or 4 (control via control line), this (automatically) switches to 1.

**Request:** <ID>'TG'<value>(CR)

<ID> Device address (2 decimal places with leading zeros)

<value> 0: Disabled/heating control

1:Telegram transmission triggered on rising edge of control voltage

2:Telegram transmission triggered on falling edge of control voltage

3:Telegram transmission while control voltage is "high"

4:Telegram transmission while control voltage is "low"

The current setting is delivered as the response if no entry is made for <value>.

**Response:** !<ID><value>(CR)

### 20.5.15 Software reset

**Description:** This command is used to trigger a software reset

**Request:** <ID>'RS1'(CR)

<ID> Device address (2 decimal places with leading zeros)

**Response:** !<ID><value>(CR)

### 20.5.16 Switchover to binary protocol

**Description:** This command is used to temporarily switch over to UMB protocol. If the switchover is to be permanent, the sensor must be configured accordingly with the aid of the UMB-Config-Tool.

**Request:** <ID>'XX'(CR)

<ID> Device address (2 decimal places with leading zeros)

**Response:** '!'<ID>'XX'(CR)

### 20.5.17 CRC Calculation

The CRC is calculated in accordance with the following rule:

The check sum is exclusive or an (XOR) of all characters of the telegram including the separators ',', but excluding '\$' and '\*'. The hexadecimal value of the upper and lower 4 bits of the result are converted into two ASCII characters (0-9,A-F) for transmission. The high byte is transmitted first.

Further information on the description of a CRC calculation is available in the NMEA 0183 protocol.

## 20.6 Communication in SDI-12 Mode

The communication in the SDI-12 mode of the WSxxx is conforming to the standard defined in „SDI-12 A Serial-Digital Interface Standard for Microprocessor-Based Sensors Version 1.3 January 12, 2009“ . The station may be operated in bus mode together with other SDI-12 sensors, connected to one SDI master (logger).


### 20.6.1 Preconditions for SDI-12 Operation

As the interface settings defined in the SDI-12 standard are significantly different from the UMB default settings, some preconditions have to be met for operation:


- Hardware version equal or higher 3.0
- Software version equal or higher 1.5
- Jumper for activation of SDI-12 mode has to be wired (see below)
- Setting for SDI-12 mode in the configuration (UMB Config Tool, V1.2 or newer)

To activate the SDI-12 mode a jumper is to be wired between control input and analog ground (pins 3 and 6 of the of the UMB round connector, or red and blue wires of the connection cable).

Using the UMB Config Tool the operation mode of the station has to be set to “SDI-12”. The baudrate will be automatically adjusted to 1200Bd by the Config Tool. The serial interface must be operated in half duplex mode



Measurement data can be transmitted alternatively in metric or US units. The selection is done by the UMB Config Tool.



When operating the device in SDI-12 mode it is basically no longer possible to access the device with the UMB Config Tool, due to the different interface parameter settings. To enable configuration access nevertheless the interface is operated in standard UMB mode for the first 5 seconds after reset / power on. If a valid UMB telegram is received within this time, the device will stay in UMB mode for the configured time out (several minutes) so that the configuration can be modified.:

- Connect the PC to the Ventus through an RS-485 converter
- Start the Config Tool and create a Ventus with the address of the actual device and activate at least one sensor. Start the measurement (will report connection error at first)
- Reset the device (Power off / on)
- When measurement values are received the measurement can be terminated, the interface is now open for configuration.



### 20.6.2 Command Set

For details of the SDI-12 protocol please refer to the above mentioned standard document.

Following commands are available for the Ventus:

**Note:** The examples in the following sections use **italics** to print the requests from the logger  
( *0V!* )

Befehl	Funktion
?!	Address search (Wildcard request, one device only on bus!)
a!	Request device active?
a!	Request device identification
aAb!	Address change to b ( 0 ... 9, A ... Z, a ... z)
aM!	Measurement, minimal base data set
aM1!	Measurement, Temperature Values
aM2!	Measurement: Wind Values
aM3!	Measurement: Air Pressure Values
aMC!	Measurement,minimal base data set, transmit values with CRC
aMC1! ... aMC3!	Measurement, (value assignment as for aMn! commands), transmission with CRC
aC!	Concurrent measurement, complete base data set
aC1! ... aC3!	Concurrent measurement, (value assignment as for aMn! Commands), extended data set
aCC!	Concurrent measurement, complete data set,, transmit values with CRC
aCC1! ... aCC3!	Concurrent measurement, complete data set,, (value assignment as for aMn! Commands), extended data set , transmit values with CRC
aD0!	Data request buffer 0
aD1!	Data request buffer 1
aD2!	Data request buffer 2
aD3!	Data request buffer 3
aD4!	Data request buffer 4
aR0!	Data request from continuous measurement, data set 0
aR1!	Data request from continuous measurement, data set 1
aR2!	Data request from continuous measurement, data set 2
aR3!	Data request from continuous measurement, data set 3
aR4!	Data request from continuous measurement, data set 4
aRC0!	Data request from continuous measurement, data set 0 with CRC
aRC1!	Data request from continuous measurement, data set 1 with CRC
aRC2!	Data request from continuous measurement, data set 2 with CRC
aRC3!	Data request from continuous measurement, data set 3 with CRC
aRC4!	Data request from continuous measurement, data set 4 with CRC
aV!	Command verification: Evaluate sensor status and heating temperatures, data request with aD0!, aD1!
aXU<m/u>!	Selection of the unit system for SDI12 data
aXH+nnnn!	Adjust the local altitude for calculation of relative air pressure
aXMn!	Select the heating mode of the device (
aXR!	Device Reset

Due the applied measurement processes the Ventus will, different from other sensors described in the SDI-12 document, always measure continuously. This causes some special properties:

- The device does not need a “Wakeup” and does not have a sleep mode. So the reactions to “Break” signals and any related timings are inapplicable. “Break” will be ignored by WS devices.
- Data requested with M- or C- commands are always available immediately. The device will always respond with a000n resp. a000nn . This means the device will not send any service request and will ignore measurement abort signals. The logger should request the data immediately.
- M- and C- command only differ in the number of values made available in the buffers (in both cases up to the maximum permitted by the standard of 9 resp. 20).
- We recommend to use the commands für continuous measurement (R-commands) to request the data.

### 20.6.3 Address Configuration

UMB Device-ID and SDI-12 Address are connected, but the different address ranges and the fact, that UMB ID's are integer numbers, while SDI-12 addresses are ASCII characters, have to be considered.

UMB Device ID1 (default) corresponds to SDI-12 Address '0' (SDI-12 default).

Valid Address Ranges:

UMB			SDI-12		
1	to	10	'0'	to	'9'
18	to	43	'A'	to	'Z'
50	to	75	'a'	to	'z'

### 20.6.4 Measurement Data Messages

In the interest of simplified evaluation the assignment of measurement values to data buffers '0' ... '9' has been defined unified for all measurement commands. For this reason the responses to C-requests are restricted to 35 characters, not using the 75 characters permitted for these requests

Currently buffers '0' bis '4' are in use.

As with M-requests max. 9 values may be transmitted, the minimal base data set has been assigned to buffers '0' and '1'. Buffers '2' to '4', which are available on request by C commands, contain further measurement values. This definition guarantees the compatibility to loggers designed according to older versions of the SDI-12 standard.

The complete range of measurement values, as defined for the UMB protocol, is available in the SDI-12 environment through the additional M and C commands (aM1! ... aM3!, aMC1! ... aMC3!, aC1! ... aC3!, aCC1! ... aCC3!).

If the measurement value is not available for some reason, e.g. sensor failure, this is indicated by a value of +999.0 or -999.9. The logger can then evaluate the reason of failure by a aV! verification request.

The following tables show the measurement values in the sequence they are arranged in the telegram (see example).

Depending on the configuration of the device the values will be transmitted in metric or US units.

**Note:** The configured system of units is not indicated in the data messages. The logger may request this setting with the I-command and adjust the evaluation of the data messages accordingly



#### Example: M Request

```

OM!
00008<CR><LF>           8 Values are available
ODO!
0+13.5+2.5+3.7+2.6<CR><LF>
Air temperature 13,5°C, curr.. wind speed 2,5m/s, max. Wind speed 3,7m/s, avg. wind speed 2,6m/s
OD1!
0+136.4+134.0+100.0+1010<CR><LF>
Curr. wind direction 136,4°, avg. wind direction(vct) 134,0°, Quality of wind measurement 100%, rel. air presssure
(curr) 1010 hPa
  
```

## Example: C Request

0C!  
000018<CR><LF> 18 Values available  
0D0!  
0+13.5+2.5+3.7+2.6<CR><LF>  
Air temperature 13,5°C, curr.. wind speed 2,5m/s, max. Wind speed 3,7m/s, avg. wind speed 2,6m/s  
0D1!  
0+136.4+134.0+100.0+1010<CR><LF>  
Curr. wind direction 136,4°, avg. wind direction(vct) 134,0°, Quality of wind measurement 100%, rel. air presssure (curr) 1010 hPa  
0D2!  
0+1.8+2.8+122.0+147.0<CR><LF>  
Wind speed (min) 1,8m/s, Wind speed (vct) 2,8m/s, Wind direction (min) 122,0°, Wind direction (max) 147,0°  
0D3!  
0+12.4+14.0+13.5<CR><LF>  
Air temperature (min) 12,4°C, air temperature (max) 14,0°C, air temperature (avg) 13,5°C  
0D4!  
0+1008+1011+1009<CR><LF>  
Rel. air pressure (min) 1008 hPa, rel. air pressure (max) 1011 hPa, rel. air pressure (avg) 1009 hPa

## 20.6.4.1 Buffer Assignment Base Data Set

Device configured for measurement values in metric units:

Measurement value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Air temperature (act)	100	-50.0	70.0	°C
Wind Speed(act)	400	0.0	75.0	m/s
Wind Speed (max)	440	0.0	75.0	m/s
Wind Speed (avg)	460	0.0	75.0	m/s
<b>Buffer '1'</b>				
Wind Direction (act)	500	0.0	359.9	°
Wind Direction (vct)	580	0.0	359.9	°
Wind Quality	805	0.0	100,0	%
Rel. Air Pressure (act)	305	300	1200	hPa
<b>Puffer '2'</b>				
Wind Speed (min)	420	0.0	75.0	m/s
Wind Speed (vct)	480	0.0	75.0	m/s
Wind Direction (min)	520	0.0	359.9	°
Wind Direction (max)	540	0.0	359.9	°
<b>Puffer '3'</b>				
Air temperature (min)	120	-50.0	70.0	°C
Air temperature (max)	140	-50.0	70.0	°C
Air temperature (avg)	160	-50.0	70.0	°C
<b>Puffer '4'</b>				
Rel. Air Pressure (min)	325	300	1200	hPa
Rel. Air Pressure (max)	345	300	1200	hPa
Rel. Air Pressure (avg)	365	300	1200	hPa

**Device configured for measurement values in US units:**

Measurement Value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Air Temperature (act)	105	-58.0	158.0	°F
Wind Speed(act)	410	0.0	167.8	Mph
Wind Speed (max)	450	0.0	167.8	mph
Wind Speed (avg)	470	0.0	167.8	mph
<b>Buffer '1'</b>				
Wind Direction (act)	500	0.0	359.9	°
Wind Direction (vct)	580	0.0	359.9	°
Wind Quality	805	0.0	100.0	%
Rel. Air Pressure (act)	305	300	1200	hPa
<b>Puffer '2'</b>				
Wind Speed (min)	430	0.0	167.8	mph
Wind Speed (vct)	490	0.0	167.8	mph
Wind Direction (min)	520	0.0	359.9	°
Wind Direction (max)	540	0.0	359.9	°
<b>Puffer '3'</b>				
Air temperature (min)	125	-58.0	158.0	°F
Air temperature (max)	145	-58.0	158.0	°F
Air temperature (avg)	165	-58.0	158.0	°F
<b>Puffer '4'</b>				
Rel. Air Pressure (min)	325	300	1200	hPa
Rel. Air Pressure (max)	345	300	1200	hPa
Rel. Air Pressure (avg)	365	300	1200	hPa

### 20.6.5 Additional Measurement Commands

With the additional measurement commands

aM1! ... aM3!

aMC1! ... aMC3! (M command, data transmission with CRC)

aC1! ... aC3!

aCC1! ... aCC3! (C command, data transmission with CRC)

the complete range of measurement data of the Ventus, as defined for the UMB protocol, is also available in a SDI-12 environment.

The measurement values are grouped according to sensor types.

As for the base data, an M command only permits to request up to 9 measurement values.

With C commands, up to 20 values are available.

The buffer assignment defined below is thus structured in a way, that the resp. M command uses the D0 and D1 buffers. If more values are available for the sensor type, the C command will also fill the buffers D2 to D4 (if required)

M1 / C1	Temperature	M: 4 Values	C: 4 Values
M2 / C2	Wind	M: 9 Values	C: 10 Values
M3 / C3	Air Pressure	M: 8 Values	C: 8 Values

## 20.6.5.1 Buffer Assignment Additional Measurement Data M1 / C1 Temperature

**Device configured for measurement values in metric units**

Measurement value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Air temperature (act)	100	-50.0	70.0	°C
Air temperature (min)	120	-50.0	70.0	°C
Air temperature (max)	140	-50.0	70.0	°C
Air temperature (avg)	160	-50.0	70.0	°C

**Device configured for measurement values in US units:**

Measurement value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Air temperature (act)	105	-58.0	158.0	°F
Air temperature (min)	125	-58.0	158.0	°F
Air temperature (max)	145	-58.0	158.0	°F
Air temperature (avg)	165	-58.0	158.0	°F

## 20.6.5.2 Buffer Assignment Additional Measurement Data M2 / C2 Wind

## Device configured for measurement values in metric units:

Measurement value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Wind Speed (act)	400	0.0	75,0	m/s
Wind Speed (min)	420	0.0	75,0	m/s
Wind Speed (max)	440	0.0	75,0	m/s
Wind Speed (avg)	460	0.0	75,0	m/s
Wind Speed (vct)	480	0.0	75,0	m/s
<b>Buffer '1'</b>				
Wind Direction (act)	500	0.0	359.9	°
Wind Direction (min)	520	0.0	359.9	°
Wind Direction (max)	540	0.0	359.9	°
Wind Direction (vct)	580	0.0	359.9	°
<b>Buffer '2'</b>				
Wind Measurement Quality	805	0.0	100.0	%

## Device configured for measurement values in US units:

Measurement value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Wind Speed (act)	410	0.0	167.8	Mph
Wind Speed (min)	430	0.0	167.8	Mph
Wind Speed (max)	450	0.0	167.8	mph
Wind Speed (avg)	470	0.0	167.8	mph
Wind Speed (vct)	490	0.0	167.8	mph
<b>Buffer '1'</b>				
Wind Direction (act)	500	0.0	359.9	°
Wind Direction (min)	520	0.0	359.9	°
Wind Direction (max)	540	0.0	359.9	°
Wind Direction (vct)	580	0.0	359.9	°
<b>Buffer '2'</b>				
Wind Measurement Quality	805	0.0	100.0	%

## 20.6.5.3 Buffer Assignment Additional Measurement Data M2 / C2 Wind

**Device configured for measurement values in metric or US units:**

Measurement value	UMB Channel	Min	Max	Unit
<b>Buffer '0'</b>				
Abs. Air Pressure (act)	300	300	1200	hPa
Abs. Air Pressure (min)	320	300	1200	hPa
Abs. Air Pressure (max)	340	300	1200	hPa
Abs. Air Pressure (avg)	360	300	1200	hPa
<b>Buffer '1'</b>				
Rel. Air Pressure (act)	305	300	1200	hPa
Rel. Air Pressure (min)	325	300	1200	hPa
Rel. Air Pressure (max)	345	300	1200	hPa
Rel. Air Pressure (avg)	365	300	1200	hPa

### 20.6.6 Message Device Identification

The device responds to the identification request with following message (example for SDI-12 device address '0':

0I!  
013Lufft.deVentusy00  
y: Metric / US units ( m = metric, u = US )

i.e. for a Ventus, configured for US units:

0I!  
013Lufft.deVentusu00

### 20.6.7 Message Verifikation

The command verification aV! is used to evaluate status information of the device. The device responds with

a0004<CR<LF>

to the request, i.e. 4 values are available in the buffers.

The first 2 "measurement values", transmitted in buffer '0' contain the status information of the measurement channels.

The status data of the channels are arranged into "fake" measurement values, each digit representing on status value. The coding of the status is listed below. Generally each sensor has to status values, one for the current measurement value, and one for the value buffer, which is used for averaging and the evaluation of minimum and maximum.

The last two values, transmitted in buffer '1', show the heating temperatures of the upper and the lower heating of the wind sensor.

Buffer '0'				
Status Group 1: +nnnn	Air temperatur,,air temperature buffer, air pressure,, air pressure buffer			
Status Group 2: +nn	Wind, wind buffer			
Buffer '1', device configured for metric units				
Measurement value	UMB Channel	min	max	Unit
Heating temp. top	112	-50	+150	°C
Heating temp. bottom	113	-50	+150	°C
Puffer '1', device configured for US units				
Heating temp. top	117	-58	+302	°F
Heating temp. bottom	118	-58	+302	°F

## Sensor status codes:

Sensor status	Code
OK	0
UNGLTG_KANAL	1
E2_CAL_ERROR	2
E2_CRC_KAL_ERR	
FLASH_CRC_ERR	
FLASH_WRITE_ERR	
FLASH_FLOAT_ERR	
MEAS_ERROR	3
MEAS_UNABLE	4
INIT_ERROR	5
VALUE_OVERFLOW	6
CHANNEL_OVERRANGE	
VALUE_UNDERFLOW	7
CHANNEL_UNDERRANGE	
BUSY	8
other sensor status	9

Example (SDI-12 Address '0', no error):

```
0V!
00004<CR><LF>
0D0!
0+0000+00<CR><LF>
0D1!
0+73.0+65.3<CR><LF>
```

Example (SDI-12 Address '0', temperature sensor failure):

```
0V!
00004<CR><LF>
0D0!
0+0300+00<CR><LF>
0D1!
0+73.0+65.3<CR><LF>
```

### 20.6.8 Message Selection of Measurement Unit System

The command is used to change the unit system used for the display of the SDI-12 data between metric and US units. The command is implemented as X command

Command: aXU<u/m>!

Response: aU<u/m><CR><LF>

u: US-Units, m: Metric Units

Example Select metric units

```
0XUm!
0Um<CR><LF>
```

### 20.6.9 Message Adjustment of the Altitude

For the calculation of the relative air pressure the local altitude (above sea level) of the device is required

Command: aXH+nnnn!

nnnn: Altitude of Sensor in m

Response: aXH+nnnn<CR><LF>

The assignment of an invalid altitude ( -100 < altitude < 5000) will be answered with aXHf<CR><LF>

Example: The altitude of the location of installation is 135m

0XH+135!

0XH+135<CR><LF>

### 20.6.10 Message setting of the Heating Mode

The heating of the sensor may be configured in different modes (see 12.5).

Command: aXMn!

n: Heating Mode (0: Off, 1: Automatic, 2: Automatic alternating)

Response: aXMnm<CR><LF>

n: selected heating mode

m: alternating

The assignment of an invalid heating mode will be answered with

aXMF<CR><LF>

Example: A Ventus shall be set to Automatic/Alternating

0XM2!

0XM11<CR><LF>

## 20.7 Kommunikation in Modbus Mode

To enable the integration of Ventus wind meters into PLC and similar environments communication with Modbus protocols is provided.

Measurement values are mapped to Modbus input registers. The range of available values is basically the same as for the UMB protocol, including the translation into different unit systems (metric, imperial ...).

In the interest of safe and simple commissioning we do not use register pairs for floating point or 32 bit integers, as the use of register pairs is not described in the Modbus standard documents. All measurement values are scaled to fit into 16bit integer registers.

### 20.7.1 Modbus Communication Parameters

The Ventus may be configured for MODBUS-RTU or MODBUS-ASCII.

For basic configuration the UMB Config Tool is used.

**Note:** If the Ventus has been configured for Modbus communication, analog output functions can not be used!

If MODBUS-RTU or MODBUS-ASCII has been selected as communication protocol in the UMB Config Tool, communication parameters are preset to 19200 Bd, even parity.

Modbus operating modes: MODBUS-RTU, MODBUS-ASCII

Baudrate: 19200 (9600, 4800 or less)

Interface settings 8E1, 8N1

**Note:** Ventus Modbus communication has been tested with 1 sec poll rate. Proper function of the device will not be guaranteed for higher poll rates.

We suggest to set the poll rate to 10 sec or slower, because generally the update rate of the measurement values is 10 sec or higher (except of the fast wind speed / wind direction channels)

Anyway for most of the weather data significant changes should be expected more in the range of minutes.

### 20.7.2 Addressing

The Modbus address is equal to the UMB address. Valid Modbus addresses are 1 to 247. If a higher UMB address has been selected, the Modbus address will be set to 247.

### 20.7.3 Modbus Functions

The functions of Conformance Class 0 and 1 have been implemented, as far as they are applicable for Ventus, i.e. all functions working on register level.

	<b>Conformance Class 0</b>	
0x03	Read Holding Registers	Selected configuration settings
0x16	Write Multiple Registers	Selected configuration settings
	<b>Conformance Class 1</b>	
0x04	Read Input Registers	Measurement values and status information
0x06	Write Single Register	Selected configuration settings
0x07	Read Exception Status	Currently not used (returns 0)
	<b>Diagnostics</b>	
0x11	Report Slave ID	(replies to broadcast address as well)

### 20.7.3.1 Function 0x03 Read Holding Registers

The Holding Registers are used to make a selected set of adjustable parameters available on Modbus also. Similar to the measurement values are mapped to 16bit integer values, if necessary by appropriate scaling

Reg. Addr.	Function	Values	Scale
0	Local Altitude	Altitude in m, for calculation of relative air pressure Value range -100 ... 5000	1.0
1	Heating operating mode	High-Byte: Heating Operating Mode Low-Byte Heating Power Mode Value range and details see 12.5	
2	Stationsreset	(function when writing only, returns always 0)	

### 20.7.3.2 Function 0x06 Write Holding Register, 0x16 Write Multiple Registers

Selected parameters of the Ventus can be adjusted by writing to the Modbus holding registers.

Register assignment see above, 20.8.2.1

The values are checked for plausibility. Improper values will not be accepted and cause a Modbus exception.

Writing the value 0x3247 (12871d) into register 2 will trigger a device reset.

### 20.7.3.3 Function 0x04 Read Input Registers

The input registers are containing the measurement values of the compact weather station and the related status information.

The measurement values are mapped to the 16bit registers using scaling factors (0 ... max. 65530 for unsigned values, -32762 ... 32762 for signed values).

Values 65535 (0xffff) resp. 32767 are used for the indication of erroneous or not available measurement values. A more detailed specification of the error can be evaluated from the status registers.

The assignment of values to the available register addresses (0 ... 124) has been arranged in a way so that the user can read the most frequently used data with few (ideally only one) register block requests

Following blocks have been defined:

- Status information
- Frequently used values which are independent of the unit system (metric / imperial) in use
- Frequently used values in metric units
- Frequently used values in imperial units
- Other measurement values

When using the metric unit system the first three blocks can supply all data usually required with one request.

There is no difference in the register assignment between the sub types of the WS family. If, dependent on the type, some value is not available, this will be indicated by setting the register to the error value..

For detailed information about measurement ranges, units etc. please refer to the related description of the UMB channels (Chapter 8 and 20.1)

Reg. Addr.	Value (UMB-Channel)	Range	Scaling, <u>signed/unsigned</u> , remarks
<b>Status information</b>			
0	Identification	Low Byte: WS-Typ (2,3,4,5,6) High Byte: Software Version	
1	Device status		
2	Sensor status 1	Air temperature, air temperature buffer, air pressure, air pressure buffer	Coding 4 bit per status, s. below
3	Sensor status 2	Wind, wind buffer	Coding 4 bit per status, s. below
4	Reserved		
5	Reserved		
6	Reserved		
7	Reserved		
8	Reserved		
9		Diagnostics: run time in 10sec steps	

Reg. Addr.	Value (UMB-Channel)	Range	Scaling, <u>signed/unsigned</u> , remarks
<b>Values Independent of the Unit System</b>			
10	305	Rel. Air Pressure (act.)	Factor 1, s
11	325	Rel. Air Pressure (min.)	Factor 1, s
12	345	Rel. Air Pressure (max.)	Factor 1, s
13	365	Rel. Air Pressure (avg.)	Factor 1, s
14	500	Wind Direction (act.)	Factor 10, s
15	520	Wind Direction (min.)	Factor 10, s
16	540	Wind Direction (max.)	Factor 10, s
17	580	Wind Direction (vct.)	Factor 10, s
18	805	Wind Measurement Quality	Factor 1, s

Reg. Addr.	Value (UMB-Channel)	Range	Scaling, <u>signed/unsigned</u> , remarks
<b>Values in Metric Units</b>			
19	100	Air Temperature °C (act.)	Factor 10, s
20	120	Air Temperature °C (min.)	Factor 10, s
21	140	Air Temperature °C (max.)	Factor 10, s
22	160	Air Temperature °C (avg.)	Factor 10, s
23	112	Heating Temperature top °C	Factor 10, s
24	113	Heating Temperature bottom °C	Factor 10, s
25	400	Wind Speed m/s (act.)	Factor 10, s
26	420	Wind Speed m/s (min.)	Factor 10, s
27	440	Wind Speed m/s (max.)	Factor 10, s
28	460	Wind Speed m/s (avg.)	Factor 10, s
29	480	Wind Speed m/s (vct.)	Factor 10, s

Reg. Addr.	Value (UMB-Channel)	Range	Scaling, <u>signed/unsigned</u> , remarks
<b>Messwerte in US-Einheiten</b>			
30	105	Air Temperature °F (act.)	Factor 10, s
31	125	Air Temperature °F (min.)	Factor 10, s
32	145	Air Temperature °F (max.)	Factor 10, s
33	165	Air Temperature °F (avg.)	Factor 10, s
34	117	Heating Temperature top °F	Factor 10, s
35	118	Heating Temperature bottom °F	Factor 10, s
36	410	Wind Speed mph (act.)	Factor 10, s
37	430	Wind Speed mph (min.)	Factor 10, s
38	450	Wind Speed mph (max.)	Factor 10, s
39	470	Wind Speed mph (avg.)	Factor 10, s
40	490	Wind Speed mph (vct.)	Factor 10, s

Reg. Addr.	Value (UMB-Channel)	Range	Scaling, <u>signed/unsigned</u> , remarks
<b>Additional Measurement Values</b>			
41	300	Abs. Air Pressure (act.)	Factor 1, s
42	320	Abs. Air Pressure (min.)	Factor 1, s
43	340	Abs. Air Pressure (max.)	Factor 1, s
44	360	Abs. Air Pressure (avg.)	Factor 1, s
45	405	Wind Speed km/h (act.)	Factor 10, s
46	425	Wind Speed km/h (min.)	Factor 10, s
47	445	Wind Speed km/h (max.)	Factor 10, s
48	465	Wind Speed km/h (avg.)	Factor 10, s
49	485	Wind Speed km/h (vct.)	Factor 10, s
50	415	Wind Speed kts (act.)	Factor 10, s
51	435	Wind Speed kts (min.)	Factor 10, s
52	455	Wind Speed kts (max.)	Factor 10, s
53	475	Wind Speed kts (avg.)	Factor 10, s
54	495	Wind Speed kts (vct.)	Factor 10, s
55			
...	Reserve		
124			

**Sensor Status:**

Each register holds 4 sensor status coded with 4 bits per status. The sequence defined in the table above is to understand as from most significant half byte to least significant half byte. Most of the sensors have two status values, one for the sensor itself and the current measurement value, another one for the buffer, from which average, min. And max values are evaluated.

Following table shows the status coding:

**Coding of Sensor Status:**

<b>Sensor State</b>	<b>Code</b>
OK	0
UNGLTG_KANAL	1
E2_CAL_ERROR E2_CRC_KAL_ERR FLASH_CRC_ERR FLASH_WRITE_ERR FLASH_FLOAT_ERR	2
MEAS_ERROR, MEAS_UNABLE	3
INIT_ERROR	4
VALUE_OVERFLOW CHANNEL_OVERRANGE VALUE_UNDERFLOW CHANNEL_UNDERRANGE	5
BUSY	6
Other Sensor State	7

## 21 List of Figures

Figure 1: Fastening to the Mast.....	12
Figure 2: North Markings.....	13
Figure 3: Alignment to North .....	13
Figure 4: Installation Sketch.....	15
Figure 5: Connections .....	16
Figure 6: Connection to ISOCON-UMB.....	19
Figure 7: Sensor Selection.....	21
Figure 8:General Settings .....	22
Figure 9:Wind Settings.....	22
Figure 10:NMEA Settings.....	23
Figure 11:Analog output Settings: Current Mode .....	23
Figure 12:Analog output Settings: Voltage Mode .....	23
Figure 13:Analog output Settings: Frequency Mode .....	24
Figure 14:Measurement Polling Channels .....	25
Figure 15:Example of Measurement Polling.....	25
Figure 16: <b>ventus</b> .....	30

## 22 Keyword Index

**G. Lufft Mess- und Regeltechnik GmbH**

Gutenbergstraße 20  
70736 Fellbach

Postfach 4252  
70719 Fellbach  
Germany

Tel: +49 711 51822-0  
Hotline: +49 711 51822-52  
Fax: +49 711 51822-41  
E-mail: [info@lufft.com](mailto:info@lufft.com)